

LAYING GARAGE CARPET & CARPET TILES

Semi Permanent Fix:



Strongbond 65 PS Vinyl & Carpet Tile Adhesive

Notched Trowel

Apply Strongbond 65 to one side only (concrete floor or tile/carpet)

Lay carpet or carpet tile

Do 1/2 square metre at a time

Smooth with a heavy Roller

Tack dry in 35 minutes

Leave overnight to dry

Permanent Fix:



Multigrass Artificial Grass Adhesive

Notched Trowel

Apply Multigrass to one side only (concrete floor)

Lay carpet or carpet tile

Smooth with a heavy Roller

Leave overnight to dry



CHECKLIST

- Respirator (Multigrass only)
- Stanley Knife
- Notched Trowel
- Gloves
- Smoothing Floor Roller

