





PAINTING EXTERIOR

Linea or Cementitious Weatherboards & Sheets

STEP 1 Ensure boards are dust free STEP 2 Apply 1x coat of Paint Plus Masonry Sealer STEP 3 Fill all fixings with Builders Bog or Fairing Cream STEP 3 Sand all boards with 180g sandpaper STEP 4 Ensure boards are dust free STEP 5 Apply 2x coats of Paint Plus HiGuard



- Stirring Stick
- Drop Sheets
- 75mm or 100mm Paint Brush
- 100mm x 10mm Nap Mini Roller Sleeves
- Paint Tray
- Work Pot
- Spray Tips
- Duster Brush
- Filler Blades
- Gap Filler
- Caulking Gun
- Orbital Sander
- 180g Sandpaper
- Clean Rags
- 24mm or 36mm Masking Tape
- Dust Mask
- Ladder
- Sunscreen, Hat & Sunglasses
- Water Drink Bottle

ACCESS: NEED SCAFFOLD?
NEED AN AIRLESS SPRAYER?

Enquire about our affordable hire rates

DISCLAIMER: This Guide has been produced with proper care, however the advice and recommendations offered within is general in nature and is subject to change without notice. Versatile Products is not responsible for the application of the advice offered and takes no responsibility for the accuracy or completeness of it. Versatile Products strongly suggest the Applicator carries out their own testing to ensure the products and processes achieve the desired result.

