





PAINTING EXTERIOR

New Weatherboards

STEP 1

Fill all nail holes with PAL Contract Filler

STEP 2

Sand weatherboards & filled holes with 180g sandpaper

STEP 3

Ensure weatherboards are dust free then spot prime with Paint Plus Quick Prep

STEP 4

Sand all spot primed areas with 220g sandpaper then ensure all weatherboards are dust free after sanding

STEP 5

Apply 2x coats of Paint Plus HiGuard



CHECKLIST

- Stirring Stick
- Drop Sheets
- 75mm or 100mm Paint Brush
- 100mm x 10mm Nap Mini Roller Sleeves
- Spray Tips
- Paint Tray
- Work Pot
- Duster Brush
- Filler Blades
- Gap Filler
- Caulking Gun
- Orbital Sander
- 180g & 220g Sanding Discs
- 180g & 220g Sanding Sheets
- Clean Rags
- 24mm or 36mm Masking Tape
- Ladder
- Sunscreen, Hat & Sunglasses
- Water Drink Bottle

ACCESS: NEED SCAFFOLD? NEED AN AIRLESS SPRAYER?

Enquire about our affordable hire rates

DISCLAIMER: This Guide has been produced with proper care, however the advice and recommendations offered within is general in nature and is subject to change without notice. Versatile Products is not responsible for the application of the advice offered and takes no responsibility for the accuracy or completeness of it. Versatile Products strongly suggest the Applicator carries out their own testing to ensure the products and processes achieve the desired result.



