





PAINTING EXTERIORStaining Weatherboards

STEP 1

Pre-rinse with Moss & Mould Killer

STEP 2

If existing stain is present apply Quantum Power Clean and then neutralise with Quantum Dex Prep

STEP 3

Pressure wash or scrub

STEP 4

Allow to dry

STEP 5

Apply 2-3 coats of Timbakote Cedar Pro OR

Enquire about our Exterior <u>Stain selections</u>



CHECKLIST

- · Stirring Stick
- Drop Sheets
- 75mm or 100mm Paint Brush
- Paint Tray
- Work Pot
- Speed Brush & Application Pad
- Duster Brush
- Latex Gloves
- Coveralls
- Dust Mask
- · Clean Rags
- Knapsack Sprayer
- Ladder
- Sunscreen, Hat & Sunglasses
- · Water Drink Bottle

ACCESS: NEED SCAFFOLD?

Enquire about our affordable hire rates

DISCLAIMER: This Guide has been produced with proper care, however the advice and recommendations offered within is general in nature and is subject to change without notice. Versatile Products is not responsible for the application of the advice offered and takes no responsibility for the accuracy or completeness of it. Versatile Products strongly suggest the Applicator carries out their own testing to ensure the products and processes achieve the desired result.



