



PAINTING INTERIOR

New Gib or Wallboard

– Ceilings (Bedrooms/Hallway/Lounge/Kitchen/Dining)

STEP 1

Spray option:
Paint Plus Seal Coat

Brush & roller option:
Paint Plus Quick Prep

STEP 2

Allow to dry

STEP 3

Sand ceilings using
150g sandpaper

STEP 4

Apply 2x coats of
Paint Plus Ceiling Flat
OR
For a wipeable option
apply 2x coats Paint Plus
Easy Flow



CHECKLIST

- Stirring Stick
- Drop Sheets
- 50-63mm Wooster or Oldfields Paint Brush
- 10-15mm Nap Two Fussy Blokes or Wooster Dacron Roller Sleeve
- Paint Tray
- Wooster Pelican Work Pot or Handy Pro Pail
- Duster Brush
- Clean Rags
- 24mm or 36mm Masking Tape
- Dust Mask
- 150g & 180g Sandpaper
- Extension Pole
- Coveralls
- Ladder
- Spray tips

NEED AN AIRLESS SPRAYER?
*Enquire about our affordable
hire rates*

DISCLAIMER: This Guide has been produced with proper care, however the advice and recommendations offered within is general in nature and is subject to change without notice. Versatile Products is not responsible for the application of the advice offered and takes no responsibility for the accuracy or completeness of it. Versatile Products strongly suggest the Applicator carries out their own testing to ensure the products and processes achieve the desired result.

13 St John Street Tauranga
07 577 0195
orders@versatileproducts.co.nz



versatile
PRODUCTS