





## **PAINTING INTERIOR**

# **New Gib or Wallboard**

- Walls (Bedrooms/Hallway/Lounge/Kitchen/Dining)

#### STEP 1

Spray option: Paint Plus Seal Coat

Brush & roller option: Paint Plus Quick Prep

## STEP 2

Allow to dry

## STEP 3

Sand walls using 150g sandpaper

#### STEP 4

Apply 2x coats of
Paint Plus Easy Flow
Lowsheen
OR
2x coats Paint Plus

**MediGuard Satin** 



#### **CHECKLIST**

- Stirring Stick
- Drop Sheets
- 50-63mm Wooster or Oldfields Paint Brush
- 10-15mm Nap Two Fussy Blokes or Wooster Dacron Roller Sleeve
- Paint Tray
- Wooster Pelican Work Pot or Handy Pro Pail
- Duster Brush
- Clean Rags
- 24mm or 36mm Masking Tape
- Dust Mask
- 150g & 180g Sandpaper
- Extension Pole
- Coveralls
- Ladder
- Spray tips

NEED AN AIRLESS SPRAYER? Enquire about our affordable hire rates







