





PAINTING INTERIOR

Painting Over Wallpaper

STEP 1 Wash walls with Sugar Soap STEP 2 Allow to dry STEP 3

STEP 4

Apply 2x coats of

Prime walls with

Multiseal Oil Based Primer

Paint Plus Easy Flow
Low Sheen
OR
2x coats Paint Plus

MediGuard Satin



CHECKLIST

- Stirring Stick
- Drop Sheets
- 50-63mm Wooster or Oldfields Paint Brush
- 10-15mm Nap Two Fussy Blokes or Wooster Dacron Roller Sleeve
- Paint Tray
- Wooster Pelican Work Pot or Handy Pro Pail
- Duster Brush
- Clean Rags
- 24mm or 36mm Masking Tape
- Ladder
- Dust Mask
- 150g & 180g Sandpaper
- Extension Pole
- Coveralls



