



PAINTING INTERIOR

Existing Ceilings or Walls

– Wet Areas (Bathroom/Ensuite/Laundry)

STEP 1

Clean all surfaces to be painted with Sugar Soap



STEP 2

Allow to dry



STEP 3

Sand walls & ceilings using 150g sandpaper



STEP 4

Apply 2x coats of Paint Plus Mediguard Anti Microbial Satin Finish

NOTE: Once painting is completed it is recommended to not use the shower or run hot water for a minimum of 7hrs



CHECKLIST

- Stirring Stick
- Drop Sheets
- 50-63mm Wooster or Oldfields Paint Brush
- 10-13mm Nap Two Fussy Blokes or Wooster Dacron Roller Sleeve
- Paint Tray
- Wooster Pelican Work Pot or Handy Pro Pail
- Duster Brush
- Clean Rags
- 24mm or 36mm Masking Tape
- Dust Mask
- 150g & 180g Sandpaper
- Extension Pole
- Coveralls
- Ladder

