



## POLYURETHANE

### Clear Coating an Interior Timber Table

#### STEP 1

Remove existing coating by sanding with the grain with 120g sandpaper



#### STEP 2

Once completely removed sand entire area with 180g sandpaper



#### STEP 3

Ensure surface is dust free



#### STEP 4

Thin Norski Polyurethane Matt or Gloss 10-15% with Turps then apply 1x coat evenly



#### STEP 5

Apply 2x full coats of Polyurethane



#### CHECKLIST

- Stirring Stick
- Drop Sheet
- 38-63mm Wooster Silvertip Paint Brush
- 230mm Two Fussy Blokes or Oldfields 5mm Nap Microfibre Roller Sleeve
- Paint Tray
- Wooster Pelican Work Pot or Handy Pro Pail
- Duster Brush
- 120g, 180g & 220g Sandpaper
- Orbital Sander
- Clean Rags
- Dust Mask
- Turpentine

#### NEED A SANDER?

We stock Festool & Metabo  
Power Tools

